



Anco Electric Airspace Heater



Includes:

- Stainless Steel Electrical Element Welded to a 3" Tri-Clamp
- Rheostat NEMA4 Controller

Element Specifications:

3,000 Watt, Single Phase, 240 Volt, 15 Amp Element.



The Rheostat control allows you to adjust the amount of electrical current running to the heating element and control the heat of the air space. The Rheostat needs to be installed by a licensed electrician.



The Air Space Heater fits into a 3" sanitary ferrule and element is self supporting. The top agitation blade helps move the air in the head space.



The element requires single phase power. It should be positioned in the tank angled to the center making sure it does not interfere with the agitator shaft or CIP spray balls.